

KP-5OMNI-EPMP3K-KIT Install Sheet

1. Secure antenna onto mounting base with M6 bolt, lock washer, flat washer.
2. Secure mounting bracket assembly and radio plate using M8 carriage bolt, nut, lock washer, and flat washer and M4 screw.

3. Secure radio to adapter plate with the screws provided with the radio.
4. Attach coax jumpers (KP-RSMA-N-8-B) between antenna and radio either before or after Step 3 but in the following order:
CH0→+45 A, CH1→-45 A, CH2→+45 B, CH3→-45 B
5. Slide radio hood into mounting base and secure using plum blossom screw.

