

100' Direct Burial Pole Process

Step 1: 36" Hole Dug



Step 2 & 3: Base Pole Section Set in Hole and Shimmed, Expanding Foamed Added



Step 3: Assembly of Slip-Jointed Pole

