
### PARTS & ACCESSORIES



#### CONCRETE BASE PLATE BPC45G\*

FOR USE WITH 3/4X12PP PIER PIN EMBEDDED IN CONCRETE.


CONCRETE BASE PLATE IS TO BE USED FOR BRACKETED AND GUYED APPLICATIONS ONLY.



#### PIER PIN 3/4X12PP

FOR USE WITH BPC45G EMBEDDED IN CONCRETE.

PIER PIN MUST BE ORDERED SEPARATELY, UNLESS BEING PURCHASED AS PART OF A COMPLETE TOWER KIT.



#### HINGED BASE PLATE BPH45G\*

FOR USE WITH 5/8X12BB BASE BOLTS (ORDERED SEPARATELY). HINGED TO ALLOW TOWER TO BE ROTATED UP FROM BASE DURING INSTALLATION.


HINGED BASE PLATE IS TO BE USED FOR BRACKETED AND GUYED APPLICATIONS ONLY.



#### **BASE BOLT**


5/8X12BB FOR USE WITH BPH45G

(6) REQUIRED, ORDERED SEPARATELY.




# **TAPERED BASE** 45TG\*

CAN BE USED WITH A4197L BASE INSULATOR OR WITH 3/4X12PP, ORDERED SEPARATELY.



#### **5' SHORT BASE** SB45G

FOR EMBEDMENT IN CONCRETE.



#### FLAT ROOF MOUNT FR45G\*


BOLTS DIRECTLY TO FLAT ROOF SURFACE.



### **SIDE ARM BRACKET**

SA253UA


MOUNTING TUBE PROVIDED IS 3' LONG, 2 - 1/4" O.D.



#### DISH MOUNT

VY4311A2 - 2 3/8" O.D. VY4311A - 4 1/2" O.D.

MAST TUBE PROVIDED IS 5'LONG.



### FACE MOUNT


DM45G2 - 2 3/8" O.D. 5' LONG DM454 - 4 1/2" O.D. 5' LONG



## HEAVY DUTY UNIVERSAL HOUSE BRACKET

**HBUTVRO** 

ADJUSTABLE TO POSITION TOWER 18" - 36" FROM WALL.



# TORQUE ARM STABILIZER ASSEMBLY

**TA45** 

ANTI-TWIST DEVICE LOCATED IN THE AREA OF ANTENNAS. PROVIDES SIX-WAY GUYING. BOLTS TO TOWER AT ANY SECTION JOINT. ATTACHED WITH JOINT BOLTS. MUST BE INSTALLED AS SECTIONS ARE JOINED TOGETHER.

\* TOWERS MOUNTED ON THESE BASES MUST BE BRACKETED OR GUYED AT ALL TIMES. TEMPORARY STEEL GUYING MAY ALSO BE NECESSARY DURING INSTALLATION AND DISMANTLING.

