

SureCall RF Signal Meter

Prod. No: SC-Meter-01

Pro-grade signal meter for measuring cellular signal



Overview

The SureCall RF signal meter measures RF signal for 4G LTE for every major carrier and 2G-3G PCS/Cellular frequencies. Extremely competitively priced, this portable signal meter is extremely versatile and sturdy. Featuring selective modes and backlit screen for dark areas, the SureCall signal meter was designed with the professional system installer in mind. With easy to use button controls, this meter is ideal for a wide variety of installer field needs and uses.

Contents

- RF Signal Meter
- Wide-Band Rubber Right-Angle Antenna
- 9" and 24" SMA-Male to N-Male connectors
- AC mini-USB Power Supply
- 4 Rechargeable AAA batteries
- User Guide

Technical Specifications

Frequency	Downlink: 728- 746 MHz / 746-757 MHz / 869894 MHz / 1930-1990 MHz 2110-2155 MHz
Input Impedance	50 ohm
Standards Supported	LTE Verizon, LTE AT&T, AWS, Cellular, PCS
Received Sensitivity	-110 dBm
Tolerance	<3 dB
AC Power Transformer	Input AC110V, 60Hz; Output: DC5V
DC Power	4 AAA PhilipsNi-Mh batteries
Power Consumption	<1.5W
RF Connector	SMA Female
Cable	RG174
Standby Working Life	3.5 hours
Active Working Life	2.5 hours
Dimensions	6.3" x 3.3" x 1.3"
Weight	7.2 oz

Features

- Measures LTE, AWS, PCS and Cellular frequencies
- Competitively priced
- High sensitivity -110dBm
- Three selectable modes—frequency bands and block power
- Backlighting for dark environment
- 3.5 hr. active working life and rechargeable
- Portable