TP-LINK[®]

TL-WN823N User Guide

300Mbps Mini Wireless N USB Adapter

Contents

Abou	ut This (Guide 1
Chap	oter 1.	Get to Know About Your Adapter 2
		t Overview
Chap	oter 2.	Connect to a Computer 5
Chap	oter 3.	Windows
3.1.	Install [Driver and Utility
3.2.		Vireless Network
	3. 2. 1.	Windows Wireless Utility 11
	3. 2. 2.	TP-LINK Utility
		WPS (Wi-Fi Protected Setup)
3.3.	Manag	ement
	3.3.1.	Status
	3.3.2.	Profile
	3.3.3.	Advanced
	3.3.4.	SoftAP
	3.3.5.	About
3.4.	Uninsta	all Driver and Utility
Chap	oter 4.	Mac OS X
4.1.	Install [Driver and Utility
4. 2.	Join a V	Vireless Network
	4.2.1.	TP-LINK Utility
	4. 2. 2.	WPS (Wi-Fi Protected Setup)
4.3.	Manag	ement
4.4.	Uninsta	all Driver and Utility
Chap	oter 5.	Linux

About This Guide

This guide is a complement to Quick Installation Guide. The Quick Installation Guide instructs you on quick Internet setup, and this guide provides details of each function and shows you the way to configure these functions appropriate to your needs.

When using this guide, please notice that features of the adapter may vary slightly depending on the model and software version you have. All screenshots, images, parameters and descriptions documented in this guide are used for demonstration only.

Conventions

In this guide, the following conventions are used:

Convention	Description
Blue Italic	Hyperlinks are in blue italic. You can click to redirect to a website or a specific section.
Blue	Contents to be emphasized and texts on the web page are in blue, including the menus, items, buttons, etc.
Note:	Ignoring this type of note might result in a malfunction or damage to the device.
Tips:	Indicates important information that helps you make better use of your device.

More Info

- The latest software and utility can be found at Download Center at *http://www.tp-link. com/support*.
- The Quick Installation Guide (QIG) can be found where you find this guide or inside the package of the product.
- Specifications can be found on the product page at *http://www.tp-link.com*.
- A Technical Support Forum is provided for you to discuss our products at *http://forum. tp-link.com*.
- Our Technical Support contact information can be found at the Contact Technical Support page at *http://www.tp-link.com/support*.

Chapter 1

Get to Know About Your Adapter

This chapter introduces what the adapter can do and shows its appearance.

This chapter contains the following sections:

- Product Overview
- LED Status

1.1. Product Overview

TP-LINK's Wireless USB Adapter connects your notebook or desktop computer to a wireless network for applications such as lag-free video streaming, online gaming, and secure Internet surfing. And the adpater has following features:

Complies with IEEE 802.11n, IEEE 802.11g, IEEE 802.11b standards

• Supports WPA/WPA2 data security, IEEE802.1x authentication, TKIP/AES encryption, WEP encryption

• Supports high rate of up to 300Mbps for maximum throughput, supports automatically adjust to lower speeds due to distance or other operating limitations

- Provides USB 2.0 interface
- Supports Ad Hoc and Infrastructure modes
- Good capability on anti-jamming
- Supports roaming between access points when configured under Infrastructure mode
- Easy to configure and provides monitoring information
- Provides internal antennas
- Supports Windows, Mac and Linux

1.2. LED Status



You can check the adapter's working status by following the LED Explanation table.

Status	Indication
Off	The driver has not been installed. The adapter's radio has been disabled.
Flashing Slowly	The driver has been installed but no data is being transmitted or received.
Flashing Quickly	Data is being transmitted or received.

Tips:


If the LED is off, try these troubleshooting tips:

- 1. Remove and reinsert the adapter.
- 2. Insert the adapter in a different USB port on your computer if one is available.
- 3. For Windows users, check the Windows device manager to see if the adapter is recognized and enabled. Reinstall the adapter software, if necessary.

Chapter 2

Connect to a Computer

Before you begin using your adapter, insert the adapter into a USB port on your computer directly.



Note:

In Windows XP, a **Found New Hardware Wizard** window will appear when the adapter is detected. Please click **Cancel**.

After connecting your adapter to the computer, please follow the instructions in the appropriate chapter for your operating system: *Windows*, *Mac OS X*, *Linux*.

Chapter 3

Windows

This chapter introduces how to install your adapter's driver and utility, use your adapter to join a wireless network, manage your adapter, and uninstall your adapter in a Windows system. The adapter is equipped with a Setup wizard, which can guide you through the installation process.

This chapter includes the following sections:

- Install Driver and Utility
- Join a Wireless Network
- Management
- Uninstall Driver and Utility


3.1. Install Driver and Utility

To set up your adapter with several easy steps quickly:

1. Insert the resource CD into your CD drive and run the Autorun.exe from the pop-up AutoPlay window. Select TL-WN823N and click Install Driver to begin.

TP-LINK The Reliable Choice		Setup Wizard
TL-WN821N	TLWN822N	TLWNB23N Install Driver User Guide
Specifications are subject to change without notice. Mor is a registered trademark of TP-LINK Technologies Co.		m. TP-LINK Browse CD EXIT


2. Follow the step-by-step instructions of the Quick Setup to complete the initial configuration.




TP-LINK Wireless Configuration Utility and Driver - Inst	tallShield Wizard
Setup Type Select the setup type that best suits your needs.	TP-LINK
Click the type of setup you prefer.	
Install Driver Only	Description
Install TP-LINK Wireless Configuration Utility and Driver	Choose this option to install the driver only, without installing the client utilities.This is the recommended option.
InstallShield	
Канотной	ick Next > Cancel

Note:

The default setup type is Install Driver Only. You can also select Install TP-LINK Wireless Configuration Utility and Driver for more functions, such as joining a wireless network via TP-LINK Utility or WPS, and managing the adapter.



TP-LINK Wireless Configuration Utility and Driver - InstallShield Wizard
Setup Status TP-LINK
InstallShield(R) Wizard is installing the driver
InstallShieldCancel



3.2. Join a Wireless Network

You can join a wireless network via Windows built-in Wireless Utility. If you want to use Option 2: TP-LINK Utility or Option 3: WPS (Wi-Fi Protected Setup) to join a wireless network, you need to install the TP-LINK Utility first.

Option 1: Windows Wireless Utility

You can use the Windows WLAN Autoconfig service (for Windows 7/8/8.1/10) and the Wireless Zero Configuration service (for Windows XP) to join a Wi-Fi network.

Option 2: TP-LINK Utility

TP-LINK Utility lets you easily connect the adapter to a Wi-Fi network and manage the adapter.

Option 3: WPS (Wi-Fi Protected Setup)

WPS (Wi-Fi Protected Setup) is a network security standard for easily adding computers and other devices to a home network. Use this method if your wireless router or access point supports WPS.

3.2.1. Windows Wireless Utility

Follow the instructions in the appropriate section below to use your computer system's built-in wireless utility: *Windows 7/8/8.1/10*, *Windows XP*.

- Windows 7/8/8.1/10
- 1. Click 🛍 , 🐗 or 🕷 (Network icon) on the taskbar. Select the Wi-Fi network you want to join, and click Connect. Enter the network password when prompted.
- 2. When the network icon changes to \mathbb{A} or \mathbb{A} , it indicates a successful network connection.

Note:

If you do not want to enter the Wi-Fi password, you can also join a wireless network either by pushing the WPS or QSS button on your router or AP, or entering the PIN of your router when the screen prompts you to do so.

- Windows XP
- 1. If you have not installed the TP-LINK Utility, go to step 2.

If you have installed the TP-LINK Utility, you need to switch to use the Windows wireless configuration tool manually using one of the following methods.

Method 1: Right-click **M** (TP-LINK Utility icon) on the taskbar. (If you do not see the icon, click the hidden icons arrow on the taskbar.) Select Switch to Windows wireless configuration tool.

Open		
Radio OFF		
Switch to Windows wireless configuration tool		
Switch to SoftAP mode		
About		
Exit		
en 🕥 🖁	1 =¥ %	Þ

Method 2: Open the TP-LINK Utility and select Advanced tab. Select Use Windows wireless configuration tool. Click OK when it prompts.

2. Right-click 🜌 (Windows XP Wireless Zero Configuration Utility icon) on the task bar, and select View Available Wireless Networks.

Change Windows Firewall settings		
Open Network Connections	The Act	. B.
Repair	Exclosured	
View Available Wireless Networks	10.06147-0.071	
EN 🔇	🖉 atl 🖻 🏂 😂 🔟	3:12 PM

3. Select the network you want to join, and click Connect. Enter your Wi-Fi password when prompted.

3.2.2. TP-LINK Utility

1. Open TP-LINK Utility 🐔 . The Network screen displays.

	WPS	6		3.3	
Status	WPS	Netwo	ork Profile	Advanced	
Network Name	e(SSID) 👻		Security =	Channel 👻	Signal 🔫
TP-LINK_7CA	.926		None	4 (2.4G)	in.
TP-LINK_Netv	work	6	WPA2-Personal	11(2.4G)	in.
TP-LINK_130	969		None	6 (2.4G)	In
TP-LINK_BF1	34C	8	WPA/WPA2-Enterpris	e 4 (2.4G)	in.
TP-LINK_130	919		None	7 (2.4G)	1000
TP-LINK_1043	3C2	8	WPA/WPA2-Personal	11 (2.4G)	1000
TPLINK_DATA	A_TRANS	8	WPA-Personal	11 (2.4G)	
TP-LINK_D34	F73	8	WEP	7 (2.4G)	ite.

2. Select the network you want to join from the list on this screen and click Connect. If you want the adapter to automatically connect to the network next time, select the Connect automatically checkbox. Enter your Wi-Fi password when prompted.

	WPS	6		3.5	
Status	WPS	Netwo	ork Profile	Advanced	
Network Nam	e(SSID) 👻		Security 👻	Channel 👻	Signal 🔻
TP-LINK_7CA	.926		None	4 (2.4G)	In
TP-LINK_Netv	vork	6	WPA2-Personal	11(2.4G)	din.
			Connect automatically	Conn	ect
TP-LINK_130	969		None	6 (2.4G)	1000
TP-LINK_BF1	34C	6	WPA/WPA2-Enterpr	ise 4 (2.4G)	ite.
TP-LINK_130	919		None	7 (2.4G)	1000
TP-LINK_104	3C2	8	WPA/WPA2-Persona	al 11 (2.4G)	1000
TPLINK DATA	TRANS	6	WPA-Personal	11 (2.4G)	1000

Note:

If your Wi-Fi network is not displayed in the list, you can try to join it by WPS or by adding a profile in the Profile screen.


3. 2. 3. WPS (Wi-Fi Protected Setup)

WPS can be activated via PBC (Push Button Configuration) and PIN code. Please refer to *PBC* or *PIN* below.

• PBC

Option 1


1. Press the WPS/QSS button on your router or AP. Within 2 minutes, press and hold the WPS button on the adapter until the following screen appears.





Option 2

1. Press the WPS/QSS button on your router or AP.



2. Open TP-LINK Utility and click WPS tab. Select Push the button on my access point or wireless router and click Connect.

TP-LIN The Reliable Choice	К				- *
	WPS		-	200	
Status	WPS	Network	Profile	Advanced	
● Push the	pose a method to e button on my ac e PIN of my acces	ion will guide you th join a wireless netw ccess point or wirele ss point or wireless ce into my access p	rork: router. router.	your wireless netwo	ork.



• PIN

Option 1

1. Open TP-LINK Utility and click WPS tab. Select Enter the PIN of my access point or wireless router. Enter the PIN of your router or AP. Click Connect.

TP-LIN	ĸ				- x
				1	
Status	WPS	Network	Profile	Advanced	
 ○ Push the ● Enter the PIN: 1349; 	ose a method to j button on my ac PIN of my acces 2564	ion will guide you th oin a wireless netw cess point or wirele ss point or wireless e into my access p	ork: ess router. router.	g your wireless network outer	c.

Note:

The default PIN of your router or AP is printed on the product label of your router or AP. If you generated a new PIN for your router, please enter the new one.



Option 2

1. Open TP-LINK Utility and click WPS tab. Select Enter the PIN of this device into my access point or wireless router. The screen displays a PIN of the adapter, which is generated randomly. Click Connect.

	к				- x
	wps		¢	1	
Status	WPS	Network	Profile	Advanced	
 Push the Enter the Enter the 	oose a method to e button on my ac e PIN of my acce	ion will guide you th join a wireless netw ccess point or wirele ss point or wireless re into my access p	ork: ess router. router.	g your wireless networ	K.
					Connect

- 2. Log in to the Web Management page of your router or AP. Go to the WPS page, enter the PIN of the adapter in the corresponding field and click Connect.
- 3. The following screen indicates a successful connection by WPS. Click OK.



3.3. Management

TP-LINK Utility provides you with an easy way to manage your adapter. It includes the following sections:

Status - View the information of the current Wi-Fi network connection and of the adapter.

Profile - Save or manage various connection settings of your Wi-Fi network.

Advanced - Turn on or off the SoftAP mode and power saving mode, switch between TP-LINK Utility and Windows Wireless Utility (for Windows XP only).

SoftAP - Configure the settings of the network shared by your adapter, and view the IP address of your adapter when it works on SoftAP mode.

About – View your adapter's Utility version and its Driver version.

Open TP-LINK Utility sand click the Status, Profile or Advanced tab to manage the corresponding section of your adapter.

3.3.1. Status

You can view the IP address and MAC address of the adapter, the signal strength of the Wi-Fi network, and other information of the network status as shown in the following figure.

	WPS		4	2 <u>6</u>
Status	WPS	Network	Profile	Advanced
Profile Name:		TP-LINK_Network		
Network Name(SSID):	TP-LINK_Network		
Network Type:		Infrastructure	Rate:	300Mbps
Channel:		9 (2.4G)	Encrypti	on Type: AES
AP MAC:		00-55-46-50-02-01	Wireless	Mode: 802.11n
IP Address:		192.168.0.101		
Signal Strength	: 💼			100% Excell

3.3.2. Profile

The Profile screen lets you save and manage different Wi-Fi connection settings as profiles so that you can quickly and simply connect to your network. Moreover, you can join a hidden Wi-Fi network that does not broadcast its SSID by adding a profile, provided that you know its wireless settings, such as SSID, security type, and encryption type. For more details, please refer to the instructions below: To add a new profile, To join a Wi-Fi network, To manage an existing profile.

					- x
Status	WPS	Network	Profile	Advanced	
Profile Name TP-LINK_Network Home		<_Network <_Network1	Network Type Infrastructure Infrastructure	Security WPA-PSK/WPA WPA-PSK/WPA	
L		Add	Modify	Remove	Connect

- To add a new profile
- 1. Click the Add button, and then a new window will open.
- 2. Complete the settings as shown in the following figure, and click Save.

Profile Name:	Home	
SSID:	TP-LINK_Network1	~
Network Type:	 Infrastructure) ad hoc
Security Type:	WPA-PSK/WPA2-PSK	¥
Encryption Type:	TKIP/AES	¥
Security Key:	*******	Show characters
Start this connec	tion automatically.	
		Save Cancel

Profile Name: Enter a name for your profile, such as Home, Office, Coffeehouse. Do not enter the profile name that already exists.

SSID: Select your Wi-Fi network from the drop-down list or enter your Wi-Fi network name manually.

Network Type: Select Infrastructure if you want to connect to a wireless router or an access point. Select ad hoc if you want to connect to another wireless client, such as an adapter.

Infrastructure:

If you select Infrastructure, you are asked to select or enter the corresponding wireless settings, which should be the same as those of your Wi-Fi network.

ad hoc:

If you select ad hoc, you are asked to configure the wireless settings for your network, including choosing the security type and the encryption type, and setting a security key.

Profile Name:	Home 2
SSID:	TP-LINK_Network2
Network Type:	Infrastructure
Security Type:	WEP
Encryption Type:	Open 👻
Key Index:	1 - ASCII_64 -
Security Key:	***** Show characters
Start this connec	tion automatically.
	Save Cancel

Note:

As for Key Index, you can select ASCII or Hexadecimal format from the drop-down list. ASCII_64 - Please enter 5 ASCII characters.

ASCII_128 - Please enter 13 ASCII characters.

Hexadecimal_64 - Please enter 10 Hexadecimal digits (any combination of 0-9, a-f, A-F, excluded space). Hexadecimal_128 - Please enter 26 Hexadecimal digits (any combination of 0-9, a-f, A-F, excluded space).

• To join a Wi-Fi network

If you want to join a Wi-Fi network that listed in the profile screen, select the profile and click Connect in the bottom right corner.

• To manage an existing profile

If you want to change the name or the wireless settings of an existing profile, select it and click Modify of the Profile screen, then you can edit the settings of this profile. If you want to delete a profile that you no longer use, select it and click Remove.

3.3.3. Advanced

TP-LINI The Reliable Choice	ĸ				- *
	WPS				
Status	WPS	Network	Profile	Advanced	_
⊚ Use TP Wireless ne Please ch SoftAP mod © ON	-LINK Wireless C twork adapter sv	witch network adapter :	🔘 Use Windo	ws wireless configura	

Select wireless configuration tool: In Windows XP, you can either use TP-LINK Utility or Windows wireless configuration tool. While in other operating systems, since you can use both TP-LINK Utility and Windows wireless configuration tool at the same time, this function is disabled.

Wireless network adapter switch: If you've installed several adapters in your computer, you can switch to another adapter among the drop-down list.


SoftAP mode: Once ON is selected, the adapter will work as an AP.

Power Save mode: Once ON is selected, the adapter will automatically reduce its power consumption when not being used.

3.3.4. SoftAP

SoftAP is short for Software enabled Access Point. When the adapter works in SoftAP mode, it allows the computer to create a wireless hotspot that other wireless devices nearby can use.

To switch to SoftAP mode, right-click the utility icon III on the task bar and select Switch to SoftAP mode.



After switching to SoftAP mode, the SoftAP icon appears in the utility. Click the SoftAP tab, and complete the settings, then click Apply for the settings to take effect.

	к					- *
	WPS		¢.			
Status	WPS	Network	Profile	A	dvanced	Soft AP
SoftAP mo	de: nnecting Share(ICS):	ON Local Area	OFF Connection	•		
SSID:		SoftAP				
Security Ty	pe:	WPA2-PS	К	•		
Encryption	Туре:	AES		•		
Security Ke	ey:	12345678			Show cł	naracters
IP Address	:	192.168.1	37.1			
						Apply

Soft AP mode: Select ON or OFF to enable or disable this function.

Internet Connecting Share(ICS): Select a network connection that can access to the Internet from the drop-down list. For example, if your computer is connecting to the Internet via an Ethernet cable, you should select the corresponding Local Area Connection so as to share the network with other wireless devices.

SSID: Set a name for the wireless network shared by your adapter. The default is SoftAP.

Security Type: The security type here is set to be WPA2-PSK which is based on 802.11i and uses AES (Advanced Encryption Standard).


Encryption Type: The encryption type here is set to be AES.

Security Key: Set a security key for the wireless network that shared by your adapter. It is recommended that you specify another key instead of the default key 12345678.

When another wireless device connects to the network shared by your adapter, it will be asked to enter the corresponding security key.

IP Address: Displays the IP address of the adapter when it works in SoftAP mode. You can also check if the network shared by your adapter is working properly by checking this IP Address. For example, if the IP Address is 0.0.0.0, it means that the Internet connection is failed.

3.3.5. About



3.4. Uninstall Driver and Utility

The software uninstallation steps vary a bit in different systems, please follow the appropriate instructions for your Windows operating system: *Windows 8/8.1/10*, *Windows XP/7*.

```
• Windows 8/8.1/10
```

Uninstall driver:

Go to Start > Apps, find the TP-LINK application. Click Uninstall - TP-LINK TL-WN823N Driver, then follow the on-screen instructions to complete the uninstallation.

Uninstall utility:

Go to Start > Apps, and find the TP-LINK application. Click Uninstall - TP-LINK Wireless Configuration Utility, then follow the on-screen instructions to complete the uninstallation.

• Windows XP/7

Uninstall driver:

Go to Start > All Programs > TP-LINK > Uninstall - TP-LINKTL-WN823N Driver. Follow the on-screen instructions to complete the uninstallation.

Uninstall utility:

Go to Start > All Programs > TP-LINK > Uninstall - TP-LINK Wireless Configuration Utility. Follow the on-screen instructions to complete the uninstallation.

Chapter 4

Mac OS X

This chapter introduces how to install your adapter's driver and utility, use your adapter to join a wireless network, manage your adapter, and uninstall your adapter in Mac OS X.


This chapter includes the following sections:

- Install Driver and Utility
- Join a Wireless Network
- Management
- Uninstall Driver and Utility

4.1. Install Driver and Utility

We take the steps in Mac OS X 10.10 as an example - the steps may vary slightly for other versions of Mac OS.

1. Insert the CD and run it manually. Open the TL-WN823N folder.




Note:

The CD is included in the package. If your CD does not work or your computer doesn't support the CD, you can also download the driver and utility from the TP-LINK website (*http://www.tp-link.com*).


2. Open the Mac OS X Driver folder.

		TL-WN82	23N	Q Search	
Driver Files	Linux Driver	Mac OS X Driver	Setup.exe	TL-WN823N_User Guide.pdf	- 1
					- 1
Utility					- 1
					- 1
					- 1
_	_	_	_	_	-


3. Double-click to unzip the Mac OS X *version.*zip file according to your computer's operating system. It will be unzipped into the Mac OS X Driver folder automatically.




4. Open the corresponding Mac OS X version folder, double click the Installer.pkg file to open the installation wizard.



5. The Install TP-LINK Wireless USB Adapter Utility and Driver Wizard window will appear. Click Continue and follow the wizard to continue the installation.







	Software License Agreement
	English
Read Me	Copyright (c) 2016 TP-LINK TECHNOLOGIES CO. All rights reserved.
License	
Destination Select	
Installation Type	
Installation	
Summary	
	Print Save Go Back Continue


Note:

The language of this utility is in accordance with the language of your computer by default, and any change of it is invalid.

		To continue insta the software lice							
ln 🗧	trodu	Click Agree to co	ntinue or c	lick Disagre	e to cancel	the instal	lation and		
• R	ead I	quit the Installer.							
• Li	icens								
D	estin	Read License			D	isagree	Agree		
ln In	stalla					lougioo	, ig. 66		
ln	stallation								
S	ummary								
		P	rint	Save			Go Back	Conti	nue







6. After restarting the computer, the TP-LINK Utility icon swill appear on the menu bar in the upper-right corner of the screen. To use the utility to join a Wi-Fi network with your adapter, refer to *Join a Wireless Network*.

Note:

If the TP-LINK Utility icon solution does not appear on the menu bar, make sure the USB wireless network adapter is connected properly and its LED is on.

4.2. Join a Wireless Network

There are two options of using the adapter to join a Wi-Fi network.

Option 1: TP-LINK Utility

TP-LINK Utility lets you easily connect the adapter to a Wi-Fi network and manage the adapter.


Option 2: WPS (Wi-Fi Protected Setup)

WPS (Wi-Fi Protected Setup) is a network security standard for easily adding computers and other devices to a home network. Use this method if your wireless router or access point supports WPS.

4.2.1. TP-LINK Utility

Option 1

Click the TP-LINK Utility icon so on the menu bar, and choose a Wi-Fi network from it. Enter the network password when prompted.



When you are connected to the Internet, the network icon will change to \blacksquare .

Option 2

- 1. Click the TP-LINK Utility icon so the menu bar, and then click Open Wireless Utility at the bottom of the network list.
- 2. Select the network you want to join from the list and enter the network password when prompted. Click Join.

5	Select the network you want to join from th enter the network password if necessary.	he list, and then
	TP-LINK_Dock_FFFF	(?
	TP-LINK_E837	ę
	TP-LINK_lotata	<u> </u>
	TP-LINK_M7350_020502	ê (Ş
	TP-LINK_Network	ê (
	Password: Show password	

Note:

If your Wi-Fi network is not displayed in the list, you can try to join it by WPS or by clicking Join Other on the above screen, and then follow the on-screen instructions to join the network.


4. 2. 2. WPS (Wi-Fi Protected Setup)

WPS can be activated via PBC (Push Button Configuration) and PIN code. Please refer to *PBC* or *PIN* below.

• PBC

Option 1


1. Press the WPS/QSS button on your router or AP. Within 2 minutes, press and hold the WPS button on the adapter until the following screen appears.






Option 2


1. Press the WPS/QSS button on your router or AP.



2. Within 2 minutes, click the TP-LINK Utility icon so the menu bar, and then click WPS at the bottom of the network list.




3. Click PBC.



4. The following screen indicates a successful connection by WPS. Click OK.

SETUP	WPS Protocol Finished !! It will connect to WPS AP automatically.	
<u> </u>		ОК
PIN	PBC	Cancel


- PIN
- 1. Click the TP-LINK Utility icon so the menu bar, and then click WPS at the bottom of the network list.



2. Click PIN.

M-FI PACIFICIES	Please key the PIN code into your AP's config page		
SETUP	PIN:	82505707	
PIN		PBC	Cancel


- 3. Within 2 minutes, log in to the Web Management page of your router or AP. Go to its WPS page, enter the PIN of the adapter in the corresponding field and click Connect.
- 4. The following screen indicates a successful connection by WPS. Click OK.



4.3. Management

TP-LINK Utility provides you with an easy way to manage various connection settings of your Wi-Fi network.

1. Click the TP-LINK Utility icon so on the menu bar, and then click Open Wireless Utility at the bottom of the network list.



2. TP-LINK Utility will pop up. Click the Profiles button to open the Profiles screen.

9	Select the network you want to join. Select the network you want to join from the list, and then enter the network password if necessary.		
	✓ TP-LINK_Network		
	TP-LINK_RE_777		
	TP-LINK_zwk_test	Ś	
	WXQCKJY		
	yrzhs		
	WXQCKJY	<u> </u>	
Join (her Profiles	Cancel Join	

3. The Profiles screen lets you manage different Wi-Fi connection settings as profiles so that you can connect to your network easily.

State	SSID	Security
0	TP-LINK_Netwo	rk WPA2 Personal
	Netowrk Name:	TP-LINK_Network
	Security:	WPA2_PSK AES
	Password:	
		Show password

Preferred Networks displays the networks that you once connected to. The networks' status and information are displayed on the table.

• To join a Wi-Fi network


If you want to join a Wi-Fi network that is listed on the profile screen, select the profile and click Apply in the bottom right corner.

• To manage an existing profile


If you want to change the wireless settings of an existing profile, select it, and then you can edit its Security and Password. If you want to delete a profile, select it and click Remove.

4.4. Uninstall Driver and Utility

- 1. Insert the CD and run it manually.
- 2. Go to TL-WN823N > Mac OS X Driver > Mac OS X version.zip > Uninstall.command.
- **3.** As shown in the figure below, a command window will pop up. Please type the password of the root user to uninstall the software.



4. Wait till the "Process completed" shows up, then the uninstallation is complete.



Chapter 5

Linux

Visit the TP-LINK's website at *http://www.tp-link.com*, and go to TL-WN823N's product page. Then find the compatible version of driver in the support page. Download and install the driver on your computer.

COPYRIGHT & TRADEMARKS

Specifications are subject to change without notice. **TP-LINK** is a registered trademark of TP-LINK TECHNOLOGIES CO., LTD. Other brands and product names are trademarks or registered trademarks of their respective holders.

No part of the specifications may be reproduced in any form or by any means or used to make any derivative such as translation, transformation, or adaptation without permission from TP-LINK TECHNOLOGIES CO., LTD. Copyright © 2017 TP-LINK TECHNOLOGIES CO., LTD. All rights reserved.

FCC STATEMENT

FC

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference.
- 2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user's authority to operate the equipment.

FCC RF Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter. This equipment has been SAR-evaluated for use in hand. SAR measurements are based on a 5mm spacing from the body and that compliance is achieved at that distance.

CE Mark Warning

This is a class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

RF Exposure Information

This device meets the EU requirements (1999/5/EC Article 3.1a) on the limitation of exposure of the general public to electromagnetic fields by way of health protection.

This device has been tested and meets the ICNIRP exposure guidelines and the European Standard EN 62209-2. SAR is measured with this device at a separation of 0.5 cm to the body, while transmitting at the highest certified output power level in all frequency bands of this device. Carry this device at least 0.5 cm away from your body to ensure exposure levels remain at or below the as-tested levels.

Canadian Compliance Statement

This device complies with Industry Canada license-exempt RSSs. Operation is subject to the following two conditions:

- 1) This device may not cause interference, and
- 2) This device must accept any interference, including interference that may cause undesired operation of the device.

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- 1) l'appareil ne doit pas produire de brouillage;
- 2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, meme si le brouillage est susceptible d'en compromettre le fonctionnement.

Radiation Exposure Statement:

This EUT is compliance with SAR for general population/uncontrolled exposure limits in RSS-102 and had been tested in accordance with the measurement methods and procedures specified in IEEE 1528 and IEC 62209. This equipment should be installed and operated with minimum distance 1.0 cm between the radiator and your body. This device and its antenna(s) must not be co-located or operating in conjunction with any other antenna or transmitter.

Industry Canada Statement

CAN ICES-3 (B)/NMB-3(B)

NCC Notice

注意!

依據 低功率電波輻射性電機管理辦法

第十二條 經型式認證合格之低功率射頻電機,非經許可,公司、商號或使用者均 不得擅自變更頻率、加大功率或變更原設計之特性或功能。

第十四條 低功率射頻電機之使用不得影響飛航安全及干擾合法通行; 經發現有干擾現象時,應立即停用,並改善至無干擾時方得繼續使用。前項合法通信,指依 電信規定作業之無線電信。低功率射頻電機需忍受合法通信或工業、科學以及醫 療用電波輻射性電機設備之干擾。

BSMI Notice

安全諮詢及注意事項

- •請使用原裝電源供應器或只能按照本產品注明的電源類型使用本產品。
- •清潔本產品之前請先拔掉電源線。請勿使用液體、噴霧清潔劑或濕布進行清 潔。
- •注意防潮,請勿將水或其他液體潑灑到本產品上。
- •插槽與開口供通風使用,以確保本產品的操作可靠並防止過熱,請勿堵塞或覆 蓋開口。
- •請勿將本產品置放於靠近熱源的地方。除非有正常的通風,否則不可放在密閉 位置中。
- •請不要私自打開機殼,不要嘗試自行維修本產品,請由授權的專業人士進行此 項工作。



Продукт сертифіковано згідно с правилами системи УкрСЕПРО на відповідність вимогам нормативних документів та вимогам, що передбачені чинними законодавчими актами України.

EHC

Safety Information

- When product has power button, the power button is one of the way to shut off the product; when there is no power button, the only way to completely shut off power is to disconnect the product or the power adapter from the power source.
- Don't disassemble the product, or make repairs yourself. You run the risk of electric shock and voiding the limited warranty. If you need service, please contact us.
- Avoid water and wet locations.

Symbol	Explanation
	RECYCLING
	This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment. User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.

Explanation of the symbols on the product label