


2. Wireless Security Setup

Your router is pre-configured with wireless security from the factory. The default wireless Pass Phrase is printed on the sticker on the bottom of the router. If you would like to change the factory set Pass Phrase, click 'Wireless 2.4GHz', then 'Wireless Security'. The Pass Phrase must have at least 8 characters. Click 'Save', then click 'Wireless 5GHz' and 'Wireless Security' to change the Pass Phrase for the 5GHz band. Once your new Pass Phrase has been entered, click 'Save', then click 'Reboot' to apply your changes.

IMPORTANT: Click the 'Reboot' button at the bottom of the page to save your settings.



The screenshot shows the 'Wireless 2.4GHz' tab selected. Under 'Wi-Fi Security Settings', the 'Select SSID' section has 'SSID choice' set to '13MS3601E1' and 'Security Mode' set to 'WPA2PSK'. The 'WPA' section shows 'WPA Algorithms' with 'TKIP' and 'AES' selected, and 'TKIPAES' also selected. The 'Pass Phrase' field is highlighted with a red rectangle and contains '*****'. The 'Key Renewal Interval' is set to '3600 sec (0 ~ 86400)'. The 'Access Policy' section has 'Policy' set to 'Disable' and 'Add a station MAC' set to an empty field with a note '(The maximum rule count is 64)'.

Figure 3

D. Setting Up Your Wireless Devices

Your wireless devices (desktop, laptop, iPad, smart-phone, etc.) must be configured to work with your wireless router. Each of these devices must have an internal or external wireless adapter and applicable drivers. User guides for each of these devices should have instructions for wireless set up. You will need the SSID and password you assigned to this wireless router during router set up. For each wireless device, access the setup menu, choose the appropriate SSID from the list of wireless networks, enter your password, and test the wireless connection.

E. Telephone Service

Contact your service provider to provision your voice service on this device.

ReadyNet

CONNECTIVITY SIMPLIFIED

AC1300MS WIRELESS AC ROUTER

Your AC1300MS has been pre-configured with an SSID (wireless network name) and security pass phrase. See the sticker on the bottom of your router for this information. If you wish to change these or other settings, use the following instructions.


www.readynetsolutions.com



QUICK INSTALLATION GUIDE

A. Connect the AC1300MS Router to Your Computer

- 1. To set up your router for the first time, please connect the router to your desktop or laptop computer as shown in the following diagram. Your broadband Internet access will generally be from a cable modem, ADSL modem, or similar device. Turn on the power switch on the back of the router.
- 2. After the hardware connections have been completed, check the status of the LED Indicators using the following table:



Note: If the LED indicator is not displaying a “Normal Status” as described in the table at left, please check the associated hardware and connections.

LED Indicator	Status	Description
RST	Reset to factory default settings	
2.4G 5G	On (Green)	Wireless access point is ready
	Blinking (Green)	It will blink while wireless traffic goes through
POWER	On (Green)	The router is powered on and running normally
	Off	The router is powered off
WAN	On (Green)	The port is connected with 1000Mbps
	Off	The port is disconnected
LAN 1/2/3/4	Blinking (Green)	It will blink while transmitting data
	On (Green)	The port is connected
	Off	The port is disconnected
Phone 1	Blinking (Green)	The data is transmitting
	On (Green)	The port is connected
	Off	The port is disconnected

Safety Notice

- The device should be placed on a flat horizontal surface, or secured safely to a wall.
- Operate equipment away from heat sources.
- Provide good air ventilation.
- Keep away from water and damp areas.
- Disconnect power from the device during severe thunderstorms.
- Use only the included AC power adapter.
- Keep router at least 20 cm away from people to reduce exposure to radio frequency emissions.

B. Log In to User Interface

- 1. Type “http://192.168.11.1” in the Address field of your web browser and press the “Enter” key. A User Name and Password dialog box will appear. The default User Name is “user” and see the sticker on the bottom of your router for the default password. Enter the user name and password then click the “Login” button.

Note: The default wireless IP address for the wireless router is 1 92.168.11.1 and the default Subnet Mask is 255.255.255.0




Figure 1

C. Configure Your Wireless SSID and Pass Phrase

1. Change SSID

To access the Wireless settings, click ‘Wireless 2.4GHz’ and then ‘Basic’. The pre-configured settings on this page will be appropriate for most settings. You might want to change the SSID and Frequency (Channel) fields. Click ‘Save’.

Once finished with changing these settings, click ‘Save’.

Click ‘Wireless 5GHz’ to configure the 5GHz band. The screen and inputs for Wireless 5GHz will be the same as for Wireless 2.4GHz. We recommend you change security passwords as indicated in Step 2. If you are finished making changes, click ‘Reboot’ at the bottom of the page to apply your changes.




Figure 2

