



Quick Installation Guide




For Mac OS X



150Mbps Wireless N Nano USB Adapter

Connect to a Computer

Insert the adapter into a USB port on your computer directly.



2 Install Driver and Utility

a. Insert the CD.

Note:

You can also download the driver and utility at http://www.tp-link.com.

b. Browse the CD, go to

TL-WN725N_WN723N > Mac OS X Driver, unzip the Mac OS X version.zip file and run the Installer.


c. Follow the wizard to complete the installation.



3 Join a Wireless Network


Via TP-LINK Utility

- a. Click (TP-LINK Wireless Configuration Utility) on the menu bar.
- b. Select your Wi-Fi network and enter the Wi-Fi password when prompted.



Connect to a Computer

Insert the adapter into a USB port on your computer directly.



In Windows XP or Windows Vista, a Found New Hardware Wizard window will appear when the adapter is detected. Please click Cancel.

2 Install Driver and Utility

a Insert the CD and run the Autorun exe from the pop-up Autoplay window.

Notes:

- 1. You can also download the driver and utility at http://www.tp-link.com.
- 2. In some operating systems, the CD screen will pop up automatically. Otherwise, run the CD manually.
- b. Select TL-WN725N and click Install Driver, then follow the InstallShield Wizard to complete the installation.

During the installation, select TP-LINK Wireless Configuration Utility and Driver if you want to use TP-LINK Utility and WPS function.




Join a Wireless Network

Option 1: Via Windows Wireless Utility

Click or (Network icon) on the task bar, select your Wi-Fi network, and click Connect.

In Windows XP, you need to close the TP-LINK Utility before

using the Windows Wireless Utility.



Option 2: Via TP-LINK Utility

Select your Wi-Fi network from the utility window and click Connect. The symbol " indicates a successful connection.





For more information, please visit our website http://www.tp-link.com @2016 TP-I INK

For Windows