




Multi Port Passive POE injector

Using your WS-POE-16-48v power injector for 802.3af or 48v devices



Before plugging in your device – please check a few things.

- Verify the power supply in the box is 48 volts?
- Is the device you will power able to handle 48 volts? If it is 802.3af – then yes.
- Are you power Cisco Pre-Standard devices – if so you need our WS-POE-Cisco jumper cable

We can answer your questions if you are not sure. Skype: wifiqos or Phone 512-479-0317

The injector block has two inputs – one screw type and one 2.1mm x 5.5mm DC jack. The same voltage must be used in both. You are able to connect one or two power supplies to the injector. The 2nd power supply will operate as either a load balancer or as a failover. See note below. You can purchase a 2nd power supply from our web page at <http://wifi-texas.com>



We also offer 24, 18, 15 and 12 volt power supplies – so if you need something else, please call.

VOIP phones, cameras and WiFi AP's need from 3 to 15 watts each, with this injector, you can provide remote power up to 328 ft from the power source. If your device data sheet shows "48v 350ma" please understand that this is not the power your device needs, but the max power that is available according to the 802.3af spec. For example, a Polycom VOIP phone is 802.3af compatible, but needs about 4.5 watts to operate. Therefore, one 12 port injector and a 60watt power supply can power 12 phones at low cost.

If the device shows "12v, PoE" on the data sheet – this usually means that the device uses 12v when powered from a transformer – and 48v when powered via CAT-5.

Connect the LAN port to your Ethernet switch. This device does 100mb max – so if there is no data sync on a gigabit Ethernet switch – try a 100mb switch or set the port to 100mb max.

URL: <http://wifi-texas.com/> Skype:wifiqos

How PoE works

A device needs power to operate. Not volts or amps – power expressed as watts. That power can be supplied at different voltages. The electronics inside the device needs usually about 3.3 or 5 volts. But at low voltages, the wires from power supply have a lot of loss beyond about 5 feet. So for short distance power, most IP phones and Cameras are shipped with a 12v or 24v power supply because 12v supplies are cheap. But these same devices, when powered via the Ethernet cable, use 48 volts. This is the 802.3af standard voltage. So a 12v 1 amp power supply for local power – when using PoE at 48v – translates to 48v .25 amps for the same power

Here is why 48v is used on Ethernet cables

The device needs power – a phone needs about 4 watts. Power loss is the current squared times the distance. With 48 volts instead of 12 volts – the loss is reduced by a factor of 4.

Is 120 watts going to damage my device?

No. High **Voltage** can damage a device, because if the **voltage** is higher than allowed, the circuitry in the device “breaks down” **drawing** a lot of **power**, and that power will melt things. But at any allowed voltage – the device takes only the power it needs to operate - you cannot “push” power.

Two power supply operation – more power?

The device has 2 power inputs. If you need more than 120 watts for all 16 devices, then connect 2 power supplies of 120 watts each. Then balance the load by connecting from the outside in – use port 1 then 16 then 2 then 15.

Redundant power supply operation?

There is a circuit between 8 and 9 that kicks in if one of the two input jacks is not connected or has lost power. Therefore if you have two power supplies of the same voltage, and one fails, the entire rack will be powered by the operating power supply. Therefore in this usage – each power supply must be large enough to power all devices. During normal operation – the load will be shared.

Other Products from WiFi-Texas



12 and 16 port rack mount



6 and 12 port gigabit



5v, USB and 12 volt active splitters

WiFi-Texas.com Inc

815-A Brazos #326
Austin Texas, 78701
512-479-0317

URL: <http://wifi-texas.com/> Skype:wifiqos